

A-MAP Mini Tester

NEW

ONE-STEP TEST PROCEDURE

BATTERY TEST

1. Touch the probes to the POS (+) & NEG (-) terminal respectively.
2. Read the voltage from the meter, then refer to the corresponding table.

	100%	75%	50%	25%	0%	
SOC	Battery Test					
OCV	12.60	12.40	12.20	12.00	11.80	WET
	12.85	12.65	12.35	12.00	11.80	GEL

ALTERNATOR TEST

1. Touch the probes to the POS (+) & NEG (-) terminal respectively when engine is running.
2. Read the LED indicators.

SPECIFICATIONS

- **VOLTAGE RANGE:** 4.5V - 39.99V
- **CABLE LENGTH:** 20.9 inch / 53CM
- **DIMENSION:** 4.7 x 2.76 x 0.71 inch (12 X 7 x 1.8 cm)
- **HOUSING MATERIAL:** Acid resistant ABS plastic
- **POWER REQUIREMENT:** Uses the power of the battery under test



OVER CHARGING OR UNDER CHARGING

GOOD ALTERNATOR

